

# USER MANUAL

## Purekeys USB Mouse

**Model:** PK-MUS-02

### Touch Scroll Sensor

Swipe your finger forward or backward over the touch sensor located between the left and right buttons to scroll. Double-tap the touch sensor to simulate a middle button function.

### Cleaning Instructions

The silicone cover is designed for quick and thorough cleaning with hospital-grade disinfectants, including 70% alcohol.

- 1. Activate cleaning mode:**
  - Press and hold the left and right buttons for **10 seconds to enter cleaning mode** (blinking green light). The mouse is now disabled to prevent unintended inputs.
- 2. Clean the mouse:**
  - Use your preferred disinfectant solution to clean the surface.
- 3. Reactivate the mouse:**
  - Press and hold left and right buttons for **4 seconds to exit cleaning mode**. The mouse is now ready for use.

### Compliance

Purekeys declares that this product complies with the essential requirements and other relevant provisions of the European Regulation 2004/108/EC.

### Responsible Party

Purekeys BV

Egersundweg 2 E, 9723 JM Groningen, Netherlands

Phone: +31507210810

Email: [info@purekeys.com](mailto:info@purekeys.com)